Hon	everile TOPEKALIN
HONEYV	ILLE DISTRIBUTOR
ELECTRONIC	C POSITION CONTROL
SER	VICE MANUAL
Model No.	
Honeyville Metal, Inc.	Phone (800) 593-8377
4200 S 900 W	Fax (260) 593-2486
Topeka, IN 46571	www.HoneyvilleMetal.com

Г

# **Specifications**

	General
Model No.	
Serial No.	
Software Version	
Dealer Name	
Order No.	
Distributor Model No.	
Distributor Serial No.	

	AC Drive Parameters		
		Factory Setting	User Setting
	Motor Parameters		
P0.00	Motor Nameplate Voltage		
P0.01	Motor Nameplate Amps		
P0.03	Motor Base RPM		
	Ramp Parameters		
P1.01	Acceleration Time 1		
P1.02	Deceleration Time 1		
	Voltz/Hertz Parameter	S	
P2.00	Volts/Hertz Settings		
P2.01	Slip Compression		
P2.10	Control Mode		
	Digital Parameters		
P3.00	Source of Operation Command		
P3.02	*Multi-Function Input DI3		
P3.04	*Multi-Function Input DI5		
	Presets Parameters		
P5.01	Multi-Speed 1		
P5.02	Multi-Speed 2		
P5.03	Multi-Speed 3		

All Parameters not listed above are at default setting.

\*P3.04 must be set before P3.02.

Power Requirements
220-240 VAC; 3 Phase; 60 Hz
440-480 VAC; 3 Phase; 60 Hz

PLC S	ettings	
	Factory Setting	User Setting
Set	tup	
Setup Password		
Alignment Factor		
Outlets		
Spacing		
Checkpoint		
Precision		
Resolution		
Ratio		
Medium Range		
Slow Range		
Green Range		
Safety Timer		
Remote Type		
Calibration Type		
Encoder Direction		
Use Nicknames		

	Factory	User
	Setting	Setting
Skip C	Dutlets	
Skip Outlet 1		
Skip Outlet 2		
Skip Outlet 3		
Skip Outlet 4		
Skip Outlet 5		
Skip Outlet 6		
Skip Outlet 7		
Skip Outlet 8		
Skip Outlet 9		
Skip Outlet 10		
Skip Outlet 10		
Skip Outlet 12		
Skip Outlet 12		
Skip Outlet 13		
Skip Outlet 14		
Skip Outlet 15		
Skip Outlet 10		
Skip Outlet 17		
Skip Outlet 10		
Skip Outlet 19		
Skip Outlet 20		
Skip Outlet 21		
Skip Outlet 22		
Skip Outlet 23		
Skip Outlet 24	amos	
Niekname 1	lames	
Nickname 2		
Nickname 3		
Nickname /		
Nickname 5		
Nickname 6		
Nickname 7		
Nickname 8		
Nickname 0		
Nickname 10		
Nickname 10		
Nickname 12		
Nickname 12		
Nickname 14		
Nickname 15		
Nickname 15		
Nickname 17		
Nickname 17		
Nickname 10		
Nickname 19		
Nickname 20		
Nickname 21		
Nickname 22		
Nickname 23		

# TABLE OF CONTENTS

Table of Contents	1-1
Introduction	2-1
Parts List	3-1
Drive Components	3-2
Drive Electrical Enclosure	
Control Electrical Enclosure	
Installation	4-1
Transportation	4-1
Environment	4-1
Disconnect Switch	4-1
Wiring	4-1
Connect the AC Lines	4-1
Connect the DC Lines	4-1
Test the Rotation	4-2
Adjusting Calibration Arm	4-2
Operation	5-1
Warning	5-1
Direction of Travel	5-1
Status Lights	5-1
Functions	5-2
Manual Function	5-2
Setup Function	5-3
Calibrate Function	5-7
Run Function	5-7
Remote Function	5-8
PLC Message Lamp	5-8
Troubleshooting	6-1
Errors	6-1
Invalid Entry	6-1
Calibration Error	6-1
Motion Errors	6-1
PLC Not Running	6-2
Emergency Procedures	6-2

External Control	1
Preparing for External Control 7-1	1
Selecting the Correct Remote Type	1
Starting the Remote Function	1
Reading the Outputs7-2	2
PLC Outputs	2
Setting the Inputs	3
PLC Inputs7-3	3
External Control Accessory Package	4
Warranty 8-1	1
Certificate of Quality	2
Field Wiring Diagram	
Control Enclosure Wiring Diagram	
Drive Enclosure Wiring Diagram	
External Control Wiring Diagram	
External Control Accessory Package Wiring Diagrams	
External Control Accessory Package Field Wiring Diagrams	
Ziplink Cable Diagrams	
Supplemental Data Sheets	

Publication History			
Issue	Date	Description of Changes	
First Edition	3/19/2010	Original Manual for EPC-GR2 with software version 3.1	
Second Edition	5/2/2011	Fixed statement and chart on 7-3	
Third Edition	8/12/2011	Added "Encoder Direction" setting	
Forth Edition	4/30/2012	Revised Parts Lists for High and Low Voltage Options	
Fifth Edition	5/24/2012	Version 3.4; Added External Control Accessory Package	

## INTRODUCTION

Thank you for purchasing a Honeyville EPC (Electronic Positioning Control) for your distributor. This manual will help you understand the operation of the control, guide you through the installation process, and give you a reference for ordering replacement parts for your control.



Honeyville Metal, Inc. 4200 S 900 W Topeka, IN 46571 Phone: (260) 593-2266 Fax: (260) 593-2486 www.HoneyvilleMetal.com This page intentionally left blank.

PARTS LIST



# **DRIVE COMPONENTS**

Item	Part	Qty	Description
1	DSSMxxxxxxE †	1	Ø 2 3/16 TGP Shaft
2		1	GR3 Drive Cabinet
3		1	Cabinet Door
4		1	GR3 Torque Arm Mount
5		1	GR3 Encoder Mount
6	DSHW1101	2	5/8"-18 Female Rod End
7	HWTR3007	1	5/8"-18 Threaded Rod x 10¾"
8	HWNT0310	4	5/8"-18 Hex Nut
9‡	PTGR1220E	1	Winsmith E30MDSND 500:1 Gear Reducer
10	PTEM3000218M	1	Black Max Y592 Motor 1/4 HP
11	DSHW1034A	1	Dynapar HS35R2000H37D Encoder
12	HWRC0003	2	3/16'' U-Bolt
13	HWCH1003	1	3/16" Chain x 19'
† Insert Dis	tributor Model (ex. D	SSM120645FI	Ξ)
‡ Flatback I	Distributors with 10 o	r more outlets	, and Round Distributors with 15 or more outlets, substitute:
9	PTGR1220	1	Winsmith 930MDSND 500:1 Gear Reducer w/ minimizer gearing

# **DRIVE COMPONENTS**



# DRIVE ELECTRICAL ENCLOSURE

	DS	ECEE02H -	High Voltage (440-480 VAC)
Item	Part	Qty	Description
1	DSHW1042	1	Fiberglass Enclosure
2	DSHW1114	1*	RF022B43AA EMI Filter
3	DSHW1115	1	DURApulse GS3-41P0 AC Drive
4	DSHW1111	1	LR-41P0 460V AC Line Reactor
5	DSHW1112	2	RF220X00A RF Filter
6	DSHW1039	1	Enclosure Heater; 60 Watt; 60/40 T-Stat
7	DSHW1008	2	Terminal Block Ground
8	DSHW1011	17	Terminal Block Blue
9	DSHW1010	1	Terminal Block Gray
10	DSHW1032	1	2 Pole Jumper Bar
11	DSHW1006	2	End Bracket
DSECEE02L - Low Voltage (220-240 VAC)			
Item	Part	Qty	Description
1	DSHW1042	1	Fiberglass Enclosure
2	DSHW1121	1*	10TDT1W4C EMI Filter
3	DSHW1117	1	DURApulse GS3-21P0 AC Drive
4	DSHW1120	1	LR-21P0 230V AC Line Reactor
5	DSHW1112	2	RF220X00A RF Filter
6	DSHW1039	1	Enclosure Heater; 60 Watt; 60/40 T-Stat
7	DSHW1008	2	Terminal Block Ground
8	DSHW1011	17	Terminal Block Blue
9	DSHW1010	1	Terminal Block Gray
10	DSHW1032	1	2 Pole Jumper Bar
11	DSHW1006	2	End Bracket
* Canada O	nly		

# DRIVE ELECTRICAL ENCLOSURE



I

# CONTROL ELECTRICAL ENCLOSURE

٦

	DSEC	CEO2H - Hic	nh Voltage (440-480 VAC)
Item	Part	Qty	Description
1	DSHW1040	1	Fiberglass Enclosure
2	DSHW1110	1	GS-41P0-FKIT Fuse Kit
3	DSEC1002	1	240/480V to 120V Transformer
4	DSHW1116	1	LC1K0910F7 IEC Mini Contactor
5	DSHW1019	1	PS24-075D 24VDC Power Supply
6	DSHW1018	1	D0-06DD1-D Direct Logic PLC
7	DSHW1006	3	End Bracket
8	DSHW1010	14	Terminal Block Grav
9	DSHW1011	20	Terminal Block Blue
10	DSHW1008	3	Terminal Block Ground
11	DSHW1032	1	2 Pole Jumper Bar
12	DSHW1032	2	3 Pole Jumper Bar
13	DSHW1032	1	4 Pole Jumper Bar
14	DSHW1032	1	6 Pole Jumper Bar
15	DSHW1082	1	30MM Selector Switch
16	DSHW1081	1	30MM Contact Block
17	DSHW1080	1	30MM Nameplate Off/On
18	DSHW1022	1	EZ-220P EZ Text Operator Panel
19	DSHW1026	1	E7-BRK-2 E7Text Mounting Clips
20*	DSHW1014	1	EZ-2CBL EZText Cable
21	DSHW1039	1†	Enclosure Heater: 60 Watt: 60/40 T-Stat
<u>.</u>	DSEC	CE02L - Lo	w Voltage (220-240 VAC)
1 10 100		~	
Tiem	Part	Oty	Description
1 0	Part DSHW1040	Oty 1	Description Fiberglass Enclosure
1 2	Part DSHW1040 DSHW1118	Oty 1 1	Description Fiberglass Enclosure GS-21P0-FKIT-3P Fuse Kit
1 2 3	Part DSHW1040 DSHW1118 DSEC1002	Oty 1 1 1	Description Fiberglass Enclosure GS-21P0-FKIT-3P Fuse Kit 240/480V to 120V Transformer LC/L/C210F7/FC0 Misi Contentor
1 2 3 4	Part DSHW1040 DSHW1118 DSEC1002 DSHW1116	Oty 1 1 1 1	Description Fiberglass Enclosure GS-21P0-FKIT-3P Fuse Kit 240/480V to 120V Transformer LC1K0910F7 IEC Mini Contactor
1 2 3 4 5	Part DSHW1040 DSHW1118 DSEC1002 DSHW1116 DSHW1019 DSHW1019	Oty 1 1 1 1 1	Description Fiberglass Enclosure GS-21P0-FKIT-3P Fuse Kit 240/480V to 120V Transformer LC1K0910F7 IEC Mini Contactor PS24-075D 24VDC Power Supply PS24-075D 24VDC Power Supply
1 2 3 4 5 6	Part DSHW1040 DSHW1118 DSEC1002 DSHW1116 DSHW1019 DSHW1018	Oty 1 1 1 1 1 1 1	Description         Fiberglass Enclosure         GS-21P0-FKIT-3P Fuse Kit         240/480V to 120V Transformer         LC1K0910F7 IEC Mini Contactor         PS24-075D 24VDC Power Supply         D0-06DD1-D Direct Logic PLC
1 2 3 4 5 6 7	Part DSHW1040 DSHW1118 DSEC1002 DSHW1116 DSHW1019 DSHW1006 DSHW1006	Oty 1 1 1 1 1 1 3 44	Description         Fiberglass Enclosure         GS-21P0-FKIT-3P Fuse Kit         240/480V to 120V Transformer         LC1K0910F7 IEC Mini Contactor         PS24-075D 24VDC Power Supply         D0-06DD1-D Direct Logic PLC         End Bracket         Tamerical Direct Data
1 2 3 4 5 6 7 8	Part DSHW1040 DSHW1118 DSEC1002 DSHW1116 DSHW1019 DSHW1018 DSHW1006 DSHW1010 DSHW1010	Oty 1 1 1 1 1 1 1 3 14	Description         Fiberglass Enclosure         GS-21P0-FKIT-3P Fuse Kit         240/480V to 120V Transformer         LC1K0910F7 IEC Mini Contactor         PS24-075D 24VDC Power Supply         D0-06DD1-D Direct Logic PLC         End Bracket         Terminal Block Gray
1 2 3 4 5 6 7 8 9	Part DSHW1040 DSHW1118 DSEC1002 DSHW1010 DSHW1019 DSHW1018 DSHW1006 DSHW10010 DSHW1011 DSHW1011	Oty 1 1 1 1 1 1 1 3 14 20 2	Description         Fiberglass Enclosure         GS-21P0-FKIT-3P Fuse Kit         240/480V to 120V Transformer         LC1K0910F7 IEC Mini Contactor         PS24-075D 24VDC Power Supply         D0-06DD1-D Direct Logic PLC         End Bracket         Terminal Block Gray         Terminal Block Blue
1 2 3 4 5 6 7 8 9 10	Part DSHW1040 DSHW1118 DSEC1002 DSHW1019 DSHW1019 DSHW1018 DSHW1006 DSHW1006 DSHW1011 DSHW1008 DSHW1008	Oty 1 1 1 1 1 1 1 3 14 20 3 4	Description         Fiberglass Enclosure         GS-21P0-FKIT-3P Fuse Kit         240/480V to 120V Transformer         LC1K0910F7 IEC Mini Contactor         PS24-075D 24VDC Power Supply         D0-06DD1-D Direct Logic PLC         End Bracket         Terminal Block Gray         Terminal Block Blue         Terminal Block Ground
1 2 3 4 5 6 7 8 9 10 11	Part DSHW1040 DSHW1118 DSEC1002 DSHW1019 DSHW1019 DSHW1006 DSHW1006 DSHW1001 DSHW10011 DSHW1008 DSHW1032 DSHW1032	Oty 1 1 1 1 1 1 1 3 14 20 3 1 2	Description         Fiberglass Enclosure         GS-21P0-FKIT-3P Fuse Kit         240/480V to 120V Transformer         LC1K0910F7 IEC Mini Contactor         PS24-075D 24VDC Power Supply         D0-06DD1-D Direct Logic PLC         End Bracket         Terminal Block Gray         Terminal Block Blue         Terminal Block Ground         2 Pole Jumper Bar         2 Dela, human Block
1 2 3 4 5 6 7 8 9 10 11 12	Part DSHW1040 DSHW1118 DSEC1002 DSHW1019 DSHW1019 DSHW1006 DSHW1006 DSHW1010 DSHW1011 DSHW1008 DSHW1032 DSHW1032	Oty           1           1           1           1           1           1           1           1           1           1           1           1           3           14           20           3           1           2           4	Description         Fiberglass Enclosure         GS-21P0-FKIT-3P Fuse Kit         240/480V to 120V Transformer         LC1K0910F7 IEC Mini Contactor         PS24-075D 24VDC Power Supply         D0-06DD1-D Direct Logic PLC         End Bracket         Terminal Block Gray         Terminal Block Blue         Terminal Block Ground         2 Pole Jumper Bar         3 Pole Jumper Bar
1 2 3 4 5 6 7 8 9 10 11 12 13	Part DSHW1040 DSHW1118 DSEC1002 DSHW1012 DSHW1019 DSHW1018 DSHW1018 DSHW1006 DSHW1006 DSHW1011 DSHW1008 DSHW1032 DSHW1032 DSHW1032	Oty 1 1 1 1 1 1 1 1 1 1 1 20 3 1 2 1 1 2 1 1 2 1 1 1 1 1 1 1 1 1 1 1 1 1	Description         Fiberglass Enclosure         GS-21P0-FKIT-3P Fuse Kit         240/480V to 120V Transformer         LC1K0910F7 IEC Mini Contactor         PS24-075D 24VDC Power Supply         D0-06DD1-D Direct Logic PLC         End Bracket         Terminal Block Gray         Terminal Block Ground         2 Pole Jumper Bar         3 Pole Jumper Bar         4 Pole Jumper Bar
1 2 3 4 5 6 7 8 9 10 11 12 13 14	Part DSHW1040 DSHW1118 DSEC1002 DSHW1019 DSHW1019 DSHW1018 DSHW1006 DSHW1006 DSHW1006 DSHW1011 DSHW1008 DSHW1032 DSHW1032 DSHW1032 DSHW1032	Oty           1           1           1           1           1           1           1           1           1           1           1           1           3           14           20           3           1           2           1           1           1	Description         Fiberglass Enclosure         GS-21P0-FKIT-3P Fuse Kit         240/480V to 120V Transformer         LC1K0910F7 IEC Mini Contactor         PS24-075D 24VDC Power Supply         D0-06DD1-D Direct Logic PLC         End Bracket         Terminal Block Gray         Terminal Block Blue         Terminal Block Ground         2 Pole Jumper Bar         3 Pole Jumper Bar         4 Pole Jumper Bar         6 Pole Jumper Bar         20MM Selector Suite
1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 10	Part DSHW1040 DSHW1118 DSEC1002 DSHW1116 DSHW1019 DSHW1019 DSHW1006 DSHW1006 DSHW1006 DSHW1008 DSHW1032 DSHW1032 DSHW1032 DSHW1032 DSHW1032 DSHW1032	Oty           1           1           1           1           1           1           1           1           1           1           1           1           1           1           2           1           1           1	Description         Fiberglass Enclosure         GS-21P0-FKIT-3P Fuse Kit         240/480V to 120V Transformer         LC1K0910F7 IEC Mini Contactor         PS24-075D 24VDC Power Supply         D0-06DD1-D Direct Logic PLC         End Bracket         Terminal Block Gray         Terminal Block Blue         Terminal Block Ground         2 Pole Jumper Bar         3 Pole Jumper Bar         4 Pole Jumper Bar         6 Pole Jumper Bar         30MM Selector Switch         20MM Context Black
1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17	Part DSHW1040 DSHW1118 DSEC1002 DSHW1116 DSHW1019 DSHW1018 DSHW1006 DSHW1006 DSHW1008 DSHW1032 DSHW1032 DSHW1032 DSHW1032 DSHW1032 DSHW1032 DSHW1032	Oty           1           1           1           1           1           1           1           1           1           1           1           1           1           20           3           14           20           3           1           2           1           1           1           1	Description         Fiberglass Enclosure         GS-21P0-FKIT-3P Fuse Kit         240/480V to 120V Transformer         LC1K0910F7 IEC Mini Contactor         PS24-075D 24VDC Power Supply         D0-06DD1-D Direct Logic PLC         End Bracket         Terminal Block Gray         Terminal Block Ground         2 Pole Jumper Bar         3 Pole Jumper Bar         4 Pole Jumper Bar         30MM Selector Switch         30MM Contact Block
1           1           2           3           4           5           6           7           8           9           10           11           12           13           14           15           16           17	Part DSHW1040 DSHW1118 DSEC1002 DSHW1116 DSHW1019 DSHW1018 DSHW1018 DSHW1006 DSHW1006 DSHW1008 DSHW1032 DSHW1032 DSHW1032 DSHW1032 DSHW1032 DSHW1032 DSHW1081 DSHW1080 DSHW1080	Oty           1	Description         Fiberglass Enclosure         GS-21P0-FKIT-3P Fuse Kit         240/480V to 120V Transformer         LC1K0910F7 IEC Mini Contactor         PS24-075D 24VDC Power Supply         D0-06DD1-D Direct Logic PLC         End Bracket         Terminal Block Gray         Terminal Block Ground         2 Pole Jumper Bar         3 Pole Jumper Bar         4 Pole Jumper Bar         30MM Selector Switch         30MM Contact Block         30MM Nameplate Off/On
1           1           2           3           4           5           6           7           8           9           10           11           12           13           14           15           16           17           18	Part DSHW1040 DSHW1118 DSEC1002 DSHW1116 DSHW1019 DSHW1019 DSHW1018 DSHW1006 DSHW1006 DSHW1008 DSHW1032 DSHW1032 DSHW1032 DSHW1032 DSHW1032 DSHW1032 DSHW1081 DSHW1080 DSHW1022	Oty           1	Description         Fiberglass Enclosure         GS-21P0-FKIT-3P Fuse Kit         240/480V to 120V Transformer         LC1K0910F7 IEC Mini Contactor         PS24-075D 24VDC Power Supply         D0-06DD1-D Direct Logic PLC         End Bracket         Terminal Block Gray         Terminal Block Ground         2 Pole Jumper Bar         3 Pole Jumper Bar         4 Pole Jumper Bar         6 Pole Jumper Bar         30MM Selector Switch         30MM Contact Block         30MM Nameplate Off/On         EZ-220P EZText Operator Panel
1         2         3         4         5         6         7         8         9         10         11         12         13         14         15         16         17         18         19	Part DSHW1040 DSHW1118 DSEC1002 DSHW1116 DSHW1019 DSHW1019 DSHW1006 DSHW1006 DSHW1006 DSHW1008 DSHW1032 DSHW1032 DSHW1032 DSHW1032 DSHW1032 DSHW1032 DSHW1081 DSHW1080 DSHW1022 DSHW1026 DSHW1026	Oty           1	Description         Fiberglass Enclosure         GS-21P0-FKIT-3P Fuse Kit         240/480V to 120V Transformer         LC1K0910F7 IEC Mini Contactor         PS24-075D 24VDC Power Supply         D0-06DD1-D Direct Logic PLC         End Bracket         Terminal Block Gray         Terminal Block Ground         2 Pole Jumper Bar         3 Pole Jumper Bar         6 Pole Jumper Bar         30MM Selector Switch         30MM Contact Block         30MM Nameplate Off/On         EZ-220P EZText Operator Panel         EZ-BRK-2 EZText Mounting Clips
1           1           2           3           4           5           6           7           8           9           10           11           12           13           14           15           16           17           18           19           20*           21	Part DSHW1040 DSHW1118 DSEC1002 DSHW1116 DSHW1019 DSHW1019 DSHW1010 DSHW1006 DSHW1006 DSHW1008 DSHW1032 DSHW1032 DSHW1032 DSHW1032 DSHW1032 DSHW1032 DSHW1032 DSHW1032 DSHW1081 DSHW1080 DSHW1080 DSHW1026 DSHW1014 DSHW1014	Oty           1           1           1           1           1           1           1           1           1           3           14           20           3           1           2           1           1           1           1           1           1           1           1           1           1           1           1	Description         Fiberglass Enclosure         GS-21P0-FKIT-3P Fuse Kit         240/480V to 120V Transformer         LC1K0910F7 IEC Mini Contactor         PS24-075D 24VDC Power Supply         D0-06DD1-D Direct Logic PLC         End Bracket         Terminal Block Gray         Terminal Block Ground         2 Pole Jumper Bar         3 Pole Jumper Bar         4 Pole Jumper Bar         30MM Selector Switch         30MM Contact Block         30MM Nameplate Off/On         EZ-220P EZText Operator Panel         EZ-2RBL EZText Cable         Explorement
Item           1           2           3           4           5           6           7           8           9           10           11           12           13           14           15           16           17           18           19           20*           21	Part DSHW1040 DSHW1118 DSEC1002 DSHW1019 DSHW1019 DSHW1018 DSHW1006 DSHW1006 DSHW1008 DSHW1032 DSHW1032 DSHW1032 DSHW1032 DSHW1032 DSHW1032 DSHW1032 DSHW1032 DSHW1032 DSHW1032 DSHW1032 DSHW1032 DSHW1033 DSHW1033 DSHW1033 DSHW1031 DSHW1031 DSHW1022 DSHW1022 DSHW1026 DSHW1039 ± Oxional	Oty           1	DescriptionFiberglass EnclosureGS-21P0-FKIT-3P Fuse Kit240/480V to 120V TransformerLC1K0910F7 IEC Mini ContactorPS24-075D 24VDC Power SupplyD0-06DD1-D Direct Logic PLCEnd BracketTerminal Block GrayTerminal Block Ground2 Pole Jumper Bar3 Pole Jumper Bar6 Pole Jumper Bar30MM Selector Switch30MM Contact Block30MM Nameplate Off/OnEZ-220P EZ Text Operator PanelEZ-2CBL EZText CableEnclosure Heater; 60 Watt; 60/40 T-Stat

# CONTROL ELECTRICAL ENCLOSURE



This page intentionally left blank.

## INSTALLATION

## Transportation

Do not put excessive stress on the drive enclosure. If the electric control is attached to a distributor, transport the distributor on its back.

#### Environment

Mount the control enclosure in a clean, dry, indoor environment. Please observe these operating temperatures:

Operating Temperatures			
	Minimum	Maximum	
Control Enclosure	40° F	120° F	
Drive Enclosure	-40° F	185° F	

If the control enclosure needs to be mounted in a location where the temperature could drop below 40° F, there is an optional enclosure heater available (HMI item # DSHW1039).

## Wiring

See diagram at right and the "Field Wiring Diagram" in the back of this manual for conduit and wiring details.

#### **Incoming Power**

- It is the responsibility of the end user to install the appropriate power disconnect between the incoming power supply and the controller.
- Do not apply power until all other wiring is complete.
- Connect incoming 3 phase AC power lines to the blue terminals labeled L1, L2, L3 and G.

#### Connect the AC Lines

- 6 conductors of 14 AWG wire are required.
- Always take the shortest distance between the control enclosure and the drive enclosure.
- Run the AC wire in its own conduit. If possible, keep 12" away from the DC lines.
- Do not allow DC lines to cross AC lines
- Connect wires to the blue terminals labeled T1, T2, T3, G, 51 and 52 in the control enclosure; connect the other end to the corresponding blue terminals in enclosure.
- Keep AC wiring to the lower left side of the control enclosure, and to the left side of the drive enclosure.



Connect the DC Lines

- 12 conductors of 18 AWG wire are required.
- For best results, use Belden 9556 or equivalent 18 AWG 6 twisted pair shielded control cable.
- Always take the shortest distance between the control enclosure and the drive enclosure.
- Run the DC cable in its own conduit. If possible, keep 12" away from AC lines.
- Do not allow DC lines to cross AC lines
- Connect wires to the blue terminals labeled 1 to 12 in the control enclosure; connect the other end to the corresponding blue terminals in the drive enclosure.
- Use a twisted pair for connections 1 & 2, 3 & 4, 5 & 6, 7 & 8, 9 & 10 and 11 & 12.
- Connect the shield to ground in the control enclosure only. Do not connect the shield to ground in the drive enclosure.
- Keep DC wiring to the lower right side of the control enclosure, and to the right side of the drive enclosure.

## Test the Rotation

When the wiring is complete, you must test the rotation of the motor. Press the "Manual" button on the Operator Panel to enter the Manual Mode. While pressing the "Up" arrow on the keypad, verify the following:

- 1. The number showing on the display should be increasing.
- 2. The spout should be rotating counter-clockwise when viewed from the top.

If the spout is rotating in the opposite direction, switch the T1 and T3 wires in the control enclosure and repeat steps 1 and 2.

## Adjust the Reference Point on the Encoder

The reference point on the encoder has been preset at

the factory. Under normal circumstances you should not need to make any changes to the reference point on the encoder.

If the encoder has been removed, please follow this procedure for setting the reference point:

- 1. Use manual mode to turn the spout to outlet 1, which is the outlet to the left of the door.
- 2. Continue to use manual mode to align then left side of the spout with the left side of outlet 1.
- 3. In the drive enclosure, remove the encoder.
- 4. Rotate the collar to align the mark on the top collar of the encoder with the center of the cord.
- 5. Align the slot in the bracket with the hole on the encoder mount.
- 6. Slide the encoder onto the shaft
- 7. Tighten the collar on the top of the encoder.
- 8. With the power on in the control enclosure, check the X2 light on the PLC. If it is lit, continue to step 10.
- 9. Loosen the bolt on the anchor tab on the encoder, and rotate the encoder slightly until the X2 light on the PLC is lit. Tighten the bolt.
- 10. Repeat steps 7 and 8 until the X2 light on the PLC is lit.
- 11. Replace the cover on the bottom of the encoder.
- 12. You will need to calibrate, and then adjust the alignment factor. See "Alignment Factor" in the "Setup Function" section of the "Operation" chapter.



## OPERATION

## **Direction of Travel**

In this documentation, forward means the spout is moving up to a higher outlet number, toward the last outlet, or counterclockwise when looking at the Distributor from above. On a Flatback Honeyville Distributor, forward is moving away from the door.

Reverse means the spout is moving down to a lower outlet number, toward the first outlet, or clockwise when looking at the Distributor from above. On a Flatback Honeyville Distributor, reverse is moving toward the door.



## Status Lights

READY	MOVING	ERROR
-------	--------	-------

Light	Color	Description	
Ready	Green	Spout is in position. Distributor is ready to be used.	
	Red	Spout is not in position. Do not use distributor.	
Moving	Yellow	Spout is in motion.	
Error	Yellow Action required. Follow on-screen instructions.		
	Red	See "Troubleshooting" chapter.	

## **Functions**

MANUAL	SETUP	CALIB	RUN	REMOTE
--------	-------	-------	-----	--------

There are five function buttons on the operator panel. Press a function button to enter a mode of operation.

If an error is generated, you will need to restart the function that you were in. Example: If you are in the Run Function and enter the number "0" as the outlet to move to, an "Invalid Entry" message will appear in the display. Press the "Run" button to return to the Run Function.

#### **Manual Function**

- Enter the Manual Function by pressing the "Manual" button on the Operator Panel.
- The Manual Function is primarily for diagnostic and maintenance purposes.
- The number displayed is the distance from the zero reference point.
- Use caution when using the Manual Function; it is possible to run the spout into the back wall of a Flatback Distributor.

#### Process

- 1. Press the Up arrow on the Operator Panel to move the spout forward.
- 2. Press the Down arrow to move the spout in reverse.

## **Setup Function**

• Enter the Setup Function by pressing the "Setup" button on the Operator Panel, then pressing the "Esc" button.

Honeyville EPC
Version 3.4
+Settings
+Skip Outlets
+Nicknames
+Status
Save Settings?

-Settings
Alignment Factor?
Outlets?
Spacing?
Checkpoint?
Precision?
Resolution?
Ratio?
Medium Range?
Slow Range?
Green Range?
Safety Timer?
Remote Type?
Calibration Type?
Encoder Direction?
Use Nicknames?
-Skip Outlets
Skip Outlet 1?
Skip Outlet 2?
Skip Outlet 24?
-Nicknames
Nickname 1?
Nickname 2?
Nickname 24?
-Status
Encoder:
Current Pos:
Target Pos:
Calib Low:
Calib High:
Green Low:
Green High:

- The Setup Function needs to be run at least once before you can start the Calibrate or Run Functions.
- Changes to settings are effective immediately; however, they will not be retained if the power is shut off unless you change the value of "Save Settings" to 1.
- If your Electronic Control was purchased with a new Honeyville Distributor, the settings have been pre-set at the factory. You should go through the Setup Function to verify the settings.
- The Setup menu is arranged in a hierarchy with folders and messages. A plus (+) is displayed in front of a folder's name if it is closed. Press the "Enter" button to open a folder. If a folder is open, a minus (-) is placed in front of the name. Any messages within that folder will be displayed below it. You may use the UP/DOWN arrow buttons to scroll down to the next message in that folder. At the end of the messages for that folder, you can press the "Esc" button to move to the previous level.
- The settings can be viewed without a password. If you need to change a setting, you are required to enter a password.
- See enclosed "Specifications Sheet" for the password and the settings described below.

#### Process

- 1. Alignment Factor
  - These adjustments ensure that the spout will lock into position when centered on the outlet.
  - You only need to set the alignment adjustments for one outlet. Assuming that all of your other settings are correct, if the alignment is set correctly for one outlet, all other outlets will also be correct.
  - If the spout is stopping to the right of center, use a smaller number.
  - If the spout is stopping to the left of center, use a larger number.
  - These adjustment numbers are obtained through a trial and error process in which the spout is moved to an outlet, and then visually inspected for centeredness.
  - During the trail and error process described above, if you have previously completed Setup and Calibration, you can press "Run" and not be forced to calibrate. You can move the outlet to a different outlet, (then back again if you wish), then press "Esc" to return to setup and enter another number and repeat the process. When you are satisfied with the position of the spout, be sure to "Save Settings" as described below.
- 2. Outlets
  - This number is equal to the number of outlets on your distributor.
- 3. Spacing
  - This number is distance between outlets on the distributor.
  - The number based on the precision setting.
  - To calculate this number, take the degrees between outlets and multiply by the precision setting, and then divide the result by 360.

- 4. Checkpoint
  - This number is the count between the two proximity switches in the drive enclosure.
  - This setting is not used on EPC-GR2 and EPC-GR3.
- 5. Precision
  - This is the number of counts for one complete revolution of the spout in the distributor.
  - This setting is 1440 on EPC-GR1; 2000 on EPC-GR2 and EPC-GR3.
- 6. Resolution
  - This is the resolution of the encoder.
  - This setting is 60 on EPC-GR1; 2000 on EPC-GR2 and EPC-GR3.
- 7. Ratio
  - This is the ratio of the gearbox if the encoder is attached to the motor. If the encoder is attached directly to the distributor shaft, this setting will be 1.
  - This setting is 500 on EPC-GR1; 1 on EPC-GR2 and EPC-GR3
- 8. Medium Range
  - As the spout approaches the target position, the motor begins to slow down. This number determines the point at which it slows from high speed to medium speed.
  - Increase this number to have the motor slow down earlier; decrease this number to have the motor slow down later.
- 9. Slow Range
  - As the spout approaches the target position, the motor begins to slow down. This number determines the point at which it slows from medium speed to slow speed.
  - Increase this number to have the motor slow down earlier; decrease this number to have the motor slow down later.
- 10. Green Range
  - This number determines the distance the spout is allowed to move off of its target before the "Ready" light changes from green to yellow.
  - Adjust this number only if the spout tends to coast past its target position and changes the "Ready" light to yellow.
  - Possible values are 0 to 3.
- 11. Safety Timer
  - If power is being sent to the motor, but there is no motion being detected by the encoder, a "Motion Error" will occur after a certain length of time. This number determines that length of time.
  - Each number represents 1/100<sup>th</sup> of a second (i.e. 50 = .5 seconds; 200 = 2.0 seconds)

#### 12. Remote Type

Use the following chart to determine which remote type is best suited for your application

Without External Control Accessory Package			
Setting	Description	Number of Outlets	
0	Binary	4 to 24	
1	Direct	4 to 8	

With External Control Accessory Package \*

		i i i i i i i i i i i i i i i i i i i
Setting	Description	Number of Outlets
0	Binary	4 to 24
1	Direct	4 to 24
* See nade 7-	4 for details	

- See the "External Control" chapter in this manual for information on implementing each • remote type
- If you are not using external control, leave this setting at 0.
- 13. Calibration Type
  - Set this number to 0 when the encoder is attached to the motor and two proximity • switches are used for calibration.
  - · If the encoder is attached directly to the distributor shaft and no proximity switches are used, set this number to 1.
- 14. Encoder Direction
  - If the encoder is counting up when the spout is moving forward, set this number to 0.
  - If the encoder is counting up when the spout is moving forward, set this number to 1.
- 15. Use Nicknames
  - You can choose to use an alternative numbering system for your outlets.
  - Set this number to 0 to disable nicknames.
  - Set this number to 1 to enable nicknames.
- 16. Skip Outlets
  - If certain outlets are not being used, you can choose to skip those outlets.
  - Set this number to 0 to use an outlet.
  - Set this number to 1 to skip an outlet
- 17. Nicknames
  - You can choose to use an alternative numbering system for your outlets.
  - If you are using nicknames, you may enter either the original number or the nickname.
  - You may assign any number between 25 and 9999 to any outlet.
  - If you have duplicate nicknames, the spout will stop at the highest outlet. Example: If outlet 2 is nicknamed "100" and if outlet 5 is nicknamed "100", when "100" is entered as the outlet to move to, the spout will go to outlet 5.
- 18. Status
  - Lists the current values for several variables within the PLC.
  - These values are used primarily for troubleshooting.

- 19. Save Settings
  - Change this number to 1 to permanently save your settings.
  - If you do not save your settings after you make a change, they will be lost when the power is shut off.
  - After saving settings, you will be required to calibrate before continuing in run mode.

## **Calibrate Function**

- Enter the Calibrate Function by pressing the "Calib" button on the Operator Panel.
- You must calibrate:
  - 1. Every time you power up
  - 2. Every time you "Save Settings"
- If the power is always on, it is recommended that you calibrate daily to verify that the equipment is functioning properly.
- If any errors are encountered during the Calibration process, a "Calibration Error" is displayed. See "Troubleshooting" for more information.

#### Process

- 1. The Motor runs in reverse until the leading edge of the Calibration Arm passes over Proximity Switch A. This sets the zero reference point.
- 2. The Motor runs forward until the Calibration Arm reaches Proximity Switch B, then compares it position with the "Checkpoint" setting.
- 3. The Motor continues forward until the spout reaches the last usable outlet, then automatically switches to the Run Function.

#### **Run Function**

- Enter the Run Function by pressing the "Run" button on the Operator Panel.
- The Setup Function and the Calibrate Function need to be completed before you can start the Run Function.

#### Process

- 1. Press "Enter" to begin input.
- 2. Use the keypad to enter the number (or nickname) of the outlet that you want to move to.
- 3. Press "Enter" again.
- 4. The spout will move to that outlet.
- 5. When the spout reaches the outlet and is locked into position, the green "Ready" light will turn on and the Distributor will be ready for operation.

## Remote Function

- Enter the Remote Function by pressing the "Remote" button on the Operator Panel.
- The Setup Function and the Calibrate Function need to be completed before you can start the Remote Function.
- While in the Remote Function, the bottom line of the display will read "Remote".
- When the green light is on, the top line shows the current outlet and the Distributor is ready for operation.
- See the "External Control" chapter for more information.

## PLC Message Lamp

- There are two types of messages on the operator panel: Setup Messages and PLC Messages.
- If the PLC Message lamp is off, you are in the Setup Messages.
- You can alternate between the two types of messages by pressing the "Esc" button.
- It is possible to enter the Setup Messages without pressing the "Setup" button. However, it is advisable to press the "Setup" button before entering "Setup" to clear any functions that are running.
- The panel locks out all key presses for 3 seconds after a PLC Message is displayed in order to ensure the operator has a chance to read the message.

This page intentionally left blank.

## TROUBLESHOOTING

## **Errors**

## Invalid Entry

Cause:

• Entering a number on the keypad that is too high or too low Action:

• Press the Function button to restart the Function that you were performing.

## **Calibration Error**

Occurs when an error is encountered during the Calibration process.

#### Causes:

- Loose or incorrect wiring
- Faulty Encoder, Speed Reducer, Motor, Starter, or PLC.

Actions:

• Check that all wiring is connected properly.

Calibration Errors		
Number	Description	
1	Arm stays over switch A.	
2	Switch B is on when arm is at switch A.	
3	Switch B turns on too soon.	
4	Arm is past switch B.	
5	No usable outlets.	

- Enter the Manual Function and press an arrow button. If the displayed number changes, the Motor and Encoder are working. If the spout moves, the Motor and Speed Reducer are working.
- Stay in the Manual Function and open the Control Enclosure. If you press the "Down" button, the "Y1" light on the PLC should light up, and the reverse side of the Starter should click in. If you press the "Up" button, the "Y0" light on the PLC should light up, and the forward side of the Starter should click in.

## **Motion Error**

Occurs when power is being sent to the Motor, but the Encoder isn't registering motion.

Causes:

- Debris or ice in Distributor
- Loose or faulty wiring.
- Faulty Encoder, Motor, Starter, or PLC.

Actions:

- Run the Calibration Function. The cause of the error might be cleared.
- Open the inspection door on the Distributor check for obstructions.
- Check that all wiring is connected properly.

#### PLC not running

Symptoms:

- No lights on Operator Panel.
- No response when pushing buttons.
- "Protocol Error" or "PLC Communication Timeout" displayed on Operator Panel.
- Run light off on the PLC.

Follow these steps to restart the PLC.

Use extreme caution; these steps must be performed with the power on.

- 1. Open the door of the Control Enclosure.
- 2. Look for a light labeled "Run" on the face of the PLC. If the light is off, continue to the next step.
- 3. Find the small silver switch on the front of the PLC. This is a three-position switch that should be in the center position.
- 4. Move the switch to the left, the back to the center position.
- 5. The "Run" light should be on.
- 6. Close the door of the Control Enclosure.

## **Emergency Procedures**

If the Motor is not working, disconnect the power, and then loosen the four bolts to drop the Motor and Encoder to the floor of the Drive Enclosure. Insert the Emergency Handle into the Speed Reducer. Each revolution of the Emergency Handle will turn the distributor spout 1/300 of a circle.

## EXTERNAL CONTROL

## **Preparing for External Control**

- 1. Your EPC can be controlled from an external system by using the inputs and outputs on the PLC as described in this chapter.
- 2. The inputs are 12-24 VDC sinking or sourcing.
- 3. The outputs are 12-24 VDC sinking.
- 4. You can use power from the 24 VDC power supply in the Control Enclosure.
- 5. See the "External Control Wiring Diagram" for additional information.

6. An optional External Control Accessory Package is available to assist you in connecting and controlling your EPC from an external system. See page 7-4 for details.

## Selecting the Correct Remote Type

1. Use the following chart to determine which remote type is best suited for your application:

Without External Control Accessory Package		
Setting	Description	Number of Outlets
0	Binary	4 to 24
1	Direct	4 to 8

Setting	Description	Number of Outlets
0	Binary	4 to 24
1	Direct	4 to 8

With External Control Accessor	v Package *
	y i achage

Setting	Description	Number of Outlets			
0	Binary	4 to 24			
1	Direct	4 to 24			

See page 7-4 for details

2. The remote type needs to be set using the setup function. See the Setup Function of the Operations chapter of this manual for more details.

## Starting the Remote Function

- 1. Every time you power up the EPC, you must calibrate before entering the Remote Function.
- 2. Enter the Remote Function by pressing the "Remote" button on the Operator Panel.
- 3. The Run Function and the Remote Function operate exclusively of each other. You cannot operate them both at the same time.

## **Reading the Outputs**

- When the EPC is in the Remote Function, output Y6 will be turned on. This indicates that it is ready to accept a command from the inputs.
- When the spout is in position and the Ready light is green, output Y7 will be turned on. The corresponding value of the current outlet will be turned on in outputs Y10-Y14. This happens whether the EPC is in Remote Function or not.

## **PLC Outputs**

			В	Binary (Remote Type 0)						Direc	ct (Rem	note Ty	/pe 1)		
	0	:1		C	2		C3		C	2		C3			
Description	Y6	Y7	Y10	Y11	Y12	Y13	Y14	Y10	Y11	Y12	Y13	Y14	Y15	Y16	Y17
Remote	1														
Ready		1													
Current: 1			1	0	0	0	0	1	0	0	0	0	0	0	0
Current: 2			0	1	0	0	0	0	1	0	0	0	0	0	0
Current: 3			1	1	0	0	0	0	0	1	0	0	0	0	0
Current: 4			0	0	1	0	0	0	0	0	1	0	0	0	0
Current: 5			1	0	1	0	0	0	0	0	0	1	0	0	0
Current: 6			0	1	1	0	0	0	0	0	0	0	1	0	0
Current: 7			1	1	1	0	0	0	0	0	0	0	0	1	0
Current: 8			0	0	0	1	0	0	0	0	0	0	0	0	1
Current: 9			1	0	0	1	0								
Current: 10			0	1	0	1	0								
Current: 11			1	1	0	1	0								
Current: 12			0	0	1	1	0								
Current: 13			1	0	1	1	0								
Current: 14			0	1	1	1	0								
Current: 15			1	1	1	1	0								
Current: 16			0	0	0	0	1								
Current: 17			1	0	0	0	1								
Current: 18			0	1	0	0	1								
Current: 19			1	1	0	0	1								
Current: 20			0	0	1	0	1								
Current: 21			1	0	1	0	1								
Current: 22			0	1	1	0	1								
Current: 23			1	1	1	0	1								
Current: 24			0	0	0	1	1								

0=Off, 1=On

## Setting the Inputs

- When the EPC is in the Remote Function, output Y6 will be turned on. You can send a
  position command by turning on the corresponding inputs X10-X14. After a one second
  delay, the spout will start turning, and output Y7 will turn off. You can turn off the inputs
  any time after output Y7 turns off. When the spout stops turning and is in position, output
  Y7 will turn back on.
- If the position command you send is the current position, output Y7 will turn off for one second, then turn back on.
- If the position command you send is higher then the number of outlets, or is an outlet that is not used (see Skip Outlets in the Setup Function section of the Operation Chapter), outputs Y6 will turn off, and the display on the operator panel will read "Invalid Entry". The operator will need to press the "Remote" button on the operator panel to restart the remote function.
- All inputs must be turned off before sending another position command.
- If the operator presses "Run" or any other function button on the operator panel, or if an error occurs, output Y6 will turn off.

	Bi	Binary (Remote Type 0)				Direct (Remote Type 1)							
		C	2		C3		C	2			C	3	
Description	X10	X11	X12	X13	X14	X10	X11	X12	X13	X14	X15	X16	X17
Move to: 1	1	0	0	0	0	1	0	0	0	0	0	0	0
Move to: 2	0	1	0	0	0	0	1	0	0	0	0	0	0
Move to: 3	1	1	0	0	0	0	0	1	0	0	0	0	0
Move to: 4	0	0	1	0	0	0	0	0	1	0	0	0	0
Move to: 5	1	0	1	0	0	0	0	0	0	1	0	0	0
Move to: 6	0	1	1	0	0	0	0	0	0	0	1	0	0
Move to: 7	1	1	1	0	0	0	0	0	0	0	0	1	0
Move to: 8	0	0	0	1	0	0	0	0	0	0	0	0	1
Move to: 9	1	0	0	1	0								
Move to: 10	0	1	0	1	0								
Move to: 11	1	1	0	1	0								
Move to: 12	0	0	1	1	0								
Move to: 13	1	0	1	1	0								
Move to: 14	0	1	1	1	0								
Move to: 15	1	1	1	1	0								
Move to: 16	0	0	0	0	1								
Move to: 17	1	0	0	0	1								
Move to: 18	0	1	0	0	1								
Move to: 19	1	1	0	0	1								
Move to: 20	0	0	1	0	1								
Move to: 21	1	0	1	0	1								
Move to: 22	0	1	1	0	1								
Move to: 23	1	1	1	0	1								
Move to: 24	0	0	0	1	1								

## PLC Inputs

0=Off, 1=On

## EXTERNAL CONTROL ACCESSORY PACKAGE

Note: this section is applicable to your EPC only if the optional EPC External Control Accessory Package has been installed.

- Simplifies the wiring for all External Control Applications.
- Allows you to use "direct" remote control type on distributors of any size.
- See "Field Wiring Diagram" for each package later in this manual for wiring details.

## Packages

Item Number	Binary (Remote Type 0)	Direct (Remote Type 1)	Compatibility
DSECEP08		Up to 8 outlets	Version 2.2 and higher
DSECEP12	Up to 24 outloto	Up to 12 outlets	Version 3.4 and higher
DSECEP18	Op to 24 outlets	Up to 18 outlets	Version 3.4 and higher
DSECEP24		Up to 24 outlets	Version 3.4 and higher

#### DSECEP08: EPC External Control Package for up to 8 Outlets - Direct, All - Binary



Term	Туре	Function	Term	Туре	Function
1	Output	Current: 1	11	Input	Move to: 1
2	Output	Current: 2	12	Input	Move to: 2
3	Output	Current: 3	13	Input	Move to: 3
4	Output	Current: 4	14	Input	Move to: 4
5	Output	Current: 5	15	Input	Move to: 5
6	Output	Current: 6	16	Input	Move to: 6
7	Output	Current: 7	17	Input	Move to: 7
8	Output	Current: 8	18	Input	Move to: 8
9	Output	Remote Mode	19	Power	24V DC -
10	Output	Ready	20	Power	24V DC +

## DSECEP12: EPC External Control Package for up to 12 Outlets - Direct



Term	Туре	Function	Term	Туре	Function
1	Output	Current: 1	21	Input	Move to: 1
2	Output	Current: 2	22	Input	Move to: 2
3	Output	Current: 3	23	Input	Move to: 3
4	Output	Current: 4	24	Input	Move to: 4
5	Output	Current: 5	25	Input	Move to: 5
6	Output	Current: 6	26	Input	Move to: 6
7	Output	Current: 7	27	Input	Move to: 7
8	Output	Current: 8	28	Input	Move to: 8
9	Output	Current: 9	29	Input	Move to: 9
10	Output	Current: 10	30	Input	Move to: 10
11	Output	Current: 11	31	Input	Move to: 11
12	Output	Current: 12	32	Input	Move to: 12
13			33		
14			34		
15			35		
16			36		
17			37		
18			38		
19	Output	Remote Mode	39	Power	24V DC -
20	Output	Ready	40	Power	24V DC +

#### 

Term	Туре	Function	Term	Туре	Function
1	Output	Current: 1	21	Input	Move to: 1
2	Output	Current: 2	22	Input	Move to: 2
3	Output	Current: 3	23	Input	Move to: 3
4	Output	Current: 4	24	Input	Move to: 4
5	Output	Current: 5	25	Input	Move to: 5
6	Output	Current: 6	26	Input	Move to: 6
7	Output	Current: 7	27	Input	Move to: 7
8	Output	Current: 8	28	Input	Move to: 8
9	Output	Current: 9	29	Input	Move to: 9
10	Output	Current: 10	30	Input	Move to: 10
11	Output	Current: 11	31	Input	Move to: 11
12	Output	Current: 12	32	Input	Move to: 12
13	Output	Current: 13	33	Input	Move to: 13
14	Output	Current: 14	34	Input	Move to: 14
15	Output	Current: 15	35	Input	Move to: 15
16	Output	Current: 16	36	Input	Move to: 16
17	Output	Current: 17	37	Input	Move to: 17
18	Output	Current: 18	38	Input	Move to: 18
19	Output	Remote Mode	39	Power	24V DC -
20	Output	Ready	40	Power	24V DC +

## DSECEP18: EPC External Control Package for up to 18 Outlets - Direct

## DSECEP24: EPC External Control Package for up to 24 Outlets - Direct



Term	Туре	Function	Term	Туре	Function
1	Output	Current: 1	26	Input	Move to: 1
2	Output	Current: 2	27	Input	Move to: 2
3	Output	Current: 3	28	Input	Move to: 3
4	Output	Current: 4	29	Input	Move to: 4
5	Output	Current: 5	30	Input	Move to: 5
6	Output	Current: 6	31	Input	Move to: 6
7	Output	Current: 7	32	Input	Move to: 7
8	Output	Current: 8	33	Input	Move to: 8
9	Output	Current: 9	34	Input	Move to: 9
10	Output	Current: 10	35	Input	Move to: 10
11	Output	Current: 11	36	Input	Move to: 11
12	Output	Current: 12	37	Input	Move to: 12
13	Output	Current: 13	38	Input	Move to: 13
14	Output	Current: 14	39	Input	Move to: 14
15	Output	Current: 15	40	Input	Move to: 15
16	Output	Current: 16	41	Input	Move to: 16
17	Output	Current: 17	42	Input	Move to: 17
18	Output	Current: 18	43	Input	Move to: 18
19	Output	Current: 19	44	Input	Move to: 19
20	Output	Current: 20	45	Input	Move to: 20
21	Output	Current: 21	46	Input	Move to: 21
22	Output	Current: 22	47	Input	Move to: 22
23	Output	Current: 23	48	Input	Move to: 23
24	Output	Current: 24	49	Input	Move to: 24
25	Output	Remote Mode	50	Output	Ready

This page intentionally left blank.

# WARRANTY

The full extent of the warranty supplied by Honeyville Metal, Inc. is to correct any defects in material and/or workmanship on the products manufactured only by Honeyville Metal, Inc. This warranty period extends for one year from the date the product arrives on the site where installation will take place. Honeyville Metal, Inc. retains the right to review and/or adjust the time period for those products that may be held in inventory at a dealer's warehouse. Honeyville Metal, Inc. retains the final authority on determining if a product is within the warranty period and if full replacement of that product is required to retain the integrity of our products reputation and meet the customer's expectations. Honeyville Metal, Inc. will not furnish labor for replacement of any defective product or components of a product. Any product that is determined defective by both Honeyville Metal, Inc. and the end user who purchased the product may not be returned to Honeyville Metal, Inc. without the receipt of Return Authorization. Returned products must be shipped to Honeyville Metal, Inc. prepaid unless instructed otherwise and must be clearly marked with a Return Merchandise Authorization (RMA) number that needs to be obtained prior to the return shipment. This warranty supplied by Honeyville Metal, Inc. excludes damage to products while in transit to the destination on all public forms of transportation except the trucking equipment owned and operated by Honeyville Metal, Inc. This warranty does not cover performance guarantees on products, only defects in material and/or workmanship as prior statement. Honeyville Metal, Inc. does honor vendor warranties that extend beyond the one year period and will pass warranty coverage on to the purchaser of that vendor product.

# **CERTIFICATE OF QUALITY**

Every effort has been made to make this equipment the best value you can obtain for your money. All the components have been inspected and assembled. The complete system has been tested to insure proper operation. We sincerely hope this equipment and our efforts meet with your approval. The full extent of Honeyville Metal, Inc. warranty is to correct any defects in material or workmanship in those products manufactured by Honeyville Metal, Inc. Motors and drives, and all electrical and air control parts carry a one-year warranty.

#### **READ INSTRUCTIONS CAREFULLY BEFORE OPERATING!**

THIS UNIT WAS FINAL INSPECTED AND PACKED BY \_\_\_\_\_











	Honeyville Metal, Inc. 4200 5 90 W. TOPEKA, INDIANA 46571 4200 5 993-2266 • FAX (260) 593-2486 FAX (260) 593-2487 FAX (260) 593-2487 FAX (260) 593-2487 FAX (260) 593-574 FAX (2
	Date:     Drawn BY: CHKED BY:       5/18/2012     CURT     MARK       FILE NAME:     08 Field Wiring dft       SHEET:     SHEET NAME:     1 of 1       SCALE:     SCALE:     SCE       DRAWN BY:      A       DSECEP08     BREW
	NOTE: NO WIRING IS REQUIRED FOR UNUSED OUTLETS. ZIPLINK CONNECTIONS <u>Term Type Function Term Type Function Term Type Function</u> <u>1 Output Current: 1 6 Output Current: 6 11 Input Move to: 1 16 Input Move to: 6 2 Output Current: 3 8 Output Current: 8 13 Input Move to: 3 18 Input Move to: 8 3 Output Current: 5 10 Output Remote Mode 14 Input Move to: 3 20 Power 24V DC- 5 Output Current: 5 10 Output Ready 15 Input Move to: 5 20 Power 24V DC-</u>



	Honeyville Metal, Inc. 4200 S 900 W. • TOPEKA, INDIANA 46571 PHONE (260) 593-2266 • FAX (260) 593-2486	EPC EXTERNAL CONTROL PACKAGE FIELD WIRING DIAGRAM	UP TO 12 OUTLETS - DIRECT
DARAWN BY: DATE DATE	5/18/2012 CURT MARK FILE NAME 12 Field Wring, dft	SHEET: SHEET NAME: 1 of 1 Sheet1 Scale: A PRAWING #: REV:	DSECEP12
Image: Strength in the strengt in the strength in the strength in the strength in the strength	I Type         Function         Term         Term         Term         Term         Term          Term <th< td=""><td>Output         Current: 4         12         Output         Current: 4         12         Output         Current: 5         13         21         Input         Move to: 1         29         Input         Move to: 9         37         27         27         10           Output         Current: 5         13         21         Input         Move to: 1         29         Input         Move to: 9         37         27         27         Input         Move to: 2         30         Input         Move to: 10         38         28         24         DC-           Output         Current: 7         15         23         Input         Move to: 3         31         Input         Move to: 10         38         24         DC-</td><td>Ourbut Current: 8 16 24 Input Move to: 4 32 Input Move to: 4 32 Input Move to: 12 40 Power 24V UC +</td></th<>	Output         Current: 4         12         Output         Current: 4         12         Output         Current: 5         13         21         Input         Move to: 1         29         Input         Move to: 9         37         27         27         10           Output         Current: 5         13         21         Input         Move to: 1         29         Input         Move to: 9         37         27         27         Input         Move to: 2         30         Input         Move to: 10         38         28         24         DC-           Output         Current: 7         15         23         Input         Move to: 3         31         Input         Move to: 10         38         24         DC-	Ourbut Current: 8 16 24 Input Move to: 4 32 Input Move to: 4 32 Input Move to: 12 40 Power 24V UC +



	Honeyville Metal, Inc. Honeyville Metal, Inc. 4200 5.90 933-2266 FAX (200) 593-2466 HONE (200) 593-2266 FAX (200) 593-2466 BPC EXTERNAL CONTROL PACKAGE FIELD WIRING DIAGRAM UP TO 18 OUTLETS - DIRECT
	DATE: 5/18/2012 CURT MARK FILE NAME: 18 Field Wing.dft SHEET: SHEET NAME: 1 of 1 Sheet1 SCALE: A DERCEP18
	NOTE: NO WIRING IS REQUIRED FOR UNUSED OUTLETS. ZIPLINK CONNECTIONS Term Type Function Term Type Function Term Type Function Term Type Function 1 Output Current: 1 9 Output Current: 17 25 Input Move to: 5 33 Input Move to: 13 2 Output Current: 2 10 Output Current: 18 26 Input Move to: 5 33 Input Move to: 13 3 Output Current: 4 12 Output Current: 19 Output Remote Mode 27 Input Move to: 6 34 Input Move to: 16 5 Output Current: 5 13 Output Current: 12 20 Output Remote Mode 27 Input Move to: 7 35 Input Move to: 16 6 Output Current: 5 13 Output Current: 13 21 Input Remote Mode 27 Input Move to: 1 29 Input Move to: 16 6 Output Current: 6 14 Output Current: 13 21 Input Move to: 1 29 Input Move to: 10 7 Output Current: 7 15 Output Current: 16 23 Input Move to: 1 29 Input Move to: 10 7 Output Current: 8 16 Output Current: 16 23 Input Move to: 1 29 Input Move to: 10 8 Output Current: 8 16 Output Current: 16 23 Input Move to: 1 29 Input Move to: 10 7 Output Current: 8 16 Output Current: 16 23 Input Move to: 1 29 Input Move to: 10 8 Output Current: 8 16 Output Current: 16 23 Input Move to: 11 33 Power 24V DC-



		Honeyville Metal, Inc. 4200 S. 900W. • TOPEKA, INDIANA 46571 PHONE (260) 593-2266 • FAX (260) 593-2486	EPC EXTERNAL CONTROL PACKAGE FIELD WIRING DIAGRAM	UP TO 24 OUTLETS - DIRECT
		DATE: DRAWN BY: CHKED BY: 5/18/2012 CURT MARK FILE NAME: 24 Field Wiring.dft	SHEET: SHEET NAME: 1 of 1 Sheet1 SCALE: A	DRAWING #: REV: DSECEP24
I     I     I     I     I     I     I     I     I       I     I     I     I     I     I     I     I     I     I       I     I     I     I     I     I     I     I     I     I       I     I     I     I     I     I     I     I     I     I       I     I     I     I     I     I     I     I     I     I       I     I     I     I     I     I     I     I     I     I       I     I     I     I     I     I     I     I     I     I       I     I     I     I     I     I     I     I     I     I       I     I     I     I     I     I     I     I     I     I       I     I     I     I     I     I     I     I     I     I       I     I     I     I     I     I     I     I     I     I       I     I     I     I     I     I     I     I     I     I       I     I     I     I     I <td>Function Term Type Function Term Type Function tr Current: 21 31 Input Move to: 6 41 Input Move to: 16</td> <td>tr     Current: 22     32     Input     Move to: 7     42     Input     Move to: 17       tr     Current: 23     33     Input     Move to: 8     43     Input     Move to: 18       tr     Current: 24     34     Input     Move to: 9     44     Input     Move to: 19       tr     Current: 24     35     Input     Move to: 10     45     Input     Move to: 20</td> <td>Move to: 1         36         Input         Move to: 11         46         Input         Move to: 21           i         Move to: 2         37         Input         Move to: 12         47         Input         Move to: 22           i         Move to: 3         38         Input         Move to: 13         48         Input         Move to: 23           Move to: 4         39         Input         Move to: 14         49         Input         Move to: 24</td> <td>Move to: 5 40 Input Move to: 15 50 Output Ready</td>	Function Term Type Function Term Type Function tr Current: 21 31 Input Move to: 6 41 Input Move to: 16	tr     Current: 22     32     Input     Move to: 7     42     Input     Move to: 17       tr     Current: 23     33     Input     Move to: 8     43     Input     Move to: 18       tr     Current: 24     34     Input     Move to: 9     44     Input     Move to: 19       tr     Current: 24     35     Input     Move to: 10     45     Input     Move to: 20	Move to: 1         36         Input         Move to: 11         46         Input         Move to: 21           i         Move to: 2         37         Input         Move to: 12         47         Input         Move to: 22           i         Move to: 3         38         Input         Move to: 13         48         Input         Move to: 23           Move to: 4         39         Input         Move to: 14         49         Input         Move to: 24	Move to: 5 40 Input Move to: 15 50 Output Ready
	NOTE: NO WIRING IS REQUIRED FOR UNUSED OUTLETS. ZIPLINK CONNECTIONS Term Type Function Term Type Function Term Type 1 Outbut Current: 1 11 Outbut Current: 11 21 Outbut	2         Output         Current: 2         12         Output         Current: 12         22         Output           3         Output         Current: 3         13         Output         Current: 13         23         Output           4         Output         Current: 4         14         Output         Current: 14         24         Output           5         Output         Current: 5         15         Output         Current: 15         25         Output	6         Output         Current: 6         16         Output         Current: 16         26         Input           7         Output         Current: 7         17         Output         Current: 17         27         Input           8         Output         Current: 8         18         Output         Current: 18         28         Input           9         Output         Current: 9         19         Output         Current: 19         29         Input	10 Output Current: 10 20 Output Current: 20 30 Input







#### D0–06DD1–D I/O Wiring Diagram

These micro PLCs feature twenty DC inputs and sixteen sinking DC outputs. The following diagram shows a typical field wiring example. The DC external power connection uses four terminals at the left as shown.

Inputs are organized into five banks of four. Each bank has an isolated common terminal, and may be wired as either sinking or sourcing inputs. The wiring example below shows all commons connected together, but separate supplies and common circuits may be used.

All outputs actually share the same common. Note the requirement for external power.



D0-06DD1-D General Specifications								
External Power Require	ements	12 – 24 VDC, 20 W maximum,						
Communication Port 1: 9600 8 data bits, 1 stop bit, or	baud (Fixed), Id parity	K–Sequence (Slave), DirectNET (Slave), MODBUS (Slave)						
Communication Port 2: 9600 baud (default), 8 data bits, 1 stop bit,odd parity		K–Sequence (Slave), DirectNET (Master/Slave), MODBUS (Master/Slave), Non-sequence/print, ASCII in/out						
Programming cable type		D2–DSCBL						
Operating Temperat	ure	32	2 to 131° F (0 to 55° C)					
Storage Temperatu	re	-4 1	-4 to 158° F (-20 to 70° C)					
Relative Humidity	/	5 to 95% (non-condensing)						
Environmental ai	r	No corrosive gases permitted						
Vibration			MIL STD 810C 514.2					
Shock			MIL STD 810C 516.2					
Noise Immunity			NEMA ICS3–304					
lerminal lype			Removable					
Wire Gauge		One 16 AWG o	or two 18 AWG, 24 AWG minimum					
	DC Input Sp	ecifications						
Parameter	High–Speed I	nputs, X0 – X3	Standard DC Inputs X4 – X23					
Min Max. Voltage Range	10.8 – 2	.6.4 VDC	10.8 – 26.4 VDC					
Operating Voltage Range	12 – 2	4 VDC	12 – 24 VDC					
Peak Voltage	30 VDC (7 kHz ma	iximum frequency)	30 VDC					
Minimum Pulse Width	70	μs	N/A					
ON Voltage Level	>10.0	) VDC	> 10.0 VDC					
OFF Voltage Level	< 2.0	VDC	< 2.0 VDC					
Max. Input Current	6mA @12VDC,	13mA @24VDC	4mA @12VDC, 8.5mA @24VDC					
Input Impedance	1.8 kΩ @ 1	2 – 24 VDC	2.8 kΩ @ 12 – 24 VDC					
Minimum ON Current	>5	mA	>4 MA					
	< 0.8	5 MA	<0.5 MA					
OFF to UN Response	(</th <th>) μs</th> <th>2 - 8  ms, 4  ms typical</th>	) μs	2 - 8  ms, 4  ms typical					
UN IU UFF Respuise	1</th <th>) μs plaide</th> <th colspan="3"></th>	) μs plaide						
	LUyit	s siue	LUgic Side					
Commons	DC Outrout C							
Descenden								
Parameter	Puise Outpi	<b>UIS, YU - YI</b>	Standard Outputs, Y2 – Y17					
Win Wax. Voltage Kange	5-3		5 – 30 VDC					
Deek Veltage	0 - 2	7 VDU	6 - 27 VDC					
On Voltage Drop								
Max Current (resistive)	0.5  VD	J @ I A	1.0.4 / point					
Max Guileni (1651511VC)	0.3 Α / μι., ΤΑ / μ 15 μΔ @	30 VDC						
Max inrush current	2 Δ for	100 ms	2 A for 100 ms					
External DC power required	20 - 28 VDC	Max 150mA	20 - 28 VDC Max 150mA					
OFF to ON Resnonse	20 20 VD0 < 11	Dus	< 10 us					
ON to OFF Resnonse	< 21	) us	< 60 us					
Status Indicators	Logic	Side	Logic Side					
Commons	4 c	channels / common x 4 banks (non-isolated)						
Fuses		None (external recommended)						

DL06 Micro PLC User Manual, 3rd Edition Rev. A 2–39

ENGINEERING SERVICE BULLETIN





# **D-90**<sup>° TYPE</sup> SPEED REDUCERS



# Installation, Operation, and Lubrication Instructions

This Engineering Service Bulletin is designed to enable users to obtain the best possible performance from their WINSMITH® Speed Reducers.

# I. SELECTION

The selection of the appropriate speed reducer for a given application requires that all factors affecting the operation of the unit be given careful consideration. Service factors must be applied to catalog ratings depending on the type of prime mover used, severity of the application and duration of daily service. If you have any questions relative to the suitability of your WINSMITH® speed reducer for your particular application, refer to the selection section of the appropriate WINSMITH catalog, or contact your WINSMITH representative or distributor.

# **II. INSTALLATION**

#### 1. Shaft Alignment

- A. The various drive members (motor, speed reducer, couplings, sprockets, sheaves, gears, etc.) should be aligned as accurately as possible to guard against unusual stresses and overloads imposed by misalignment.
- **B.** If a prime mover shaft is to be directly connected to the high speed (input) shaft or if the slow speed (output) shaft is to be directly connected to the driven shaft, flexible couplings should be used. It should be remembered that even flexible couplings have limited ability to accommodate misalignment. Care must be taken at installation to insure that shaft alignments are within the limits recommended by the coupling manufacturer. Use of a rigid coupling to connect speed reducer shafts to other drive components is not recommended as it is almost impossible to obtain exact alignment between two shafts.
- **C.** A common base plate supporting the motor and reducer will help preserve the original alignment between reducer and motor shafts. If a structural steel base is used, the plate should be at least equal in thickness to the diameter of the bolts used to fasten the speed reducer to the base plate. Also, for sufficient rigidity, the design in general including angle or channel members should be substantial enough to prevent flexing under vibration. After the first week or two of operation all of the bolts and nuts used to fasten the reducer and motor, pedestal, etc., to the base plate should be retightened. Vibration tends to loosen the nuts even if tight initially. Dowelling the motor and speed reducer to the base plate will help insure that alignment is maintained.

#### 2. Mounting Positions

**A.** Single reduction units are designed to accommodate most standard mounting positions. Figure

1 illustrates the utility plug locations for each based on model. All standard single reduction models are equipped with an internal splash shield located near the worm. This shield deflects the oil from the vent, preventing leakage when the vent plug is adjacent to the worm (as on the DT or DV standard mounting). When this location is used as a drain (as on the DV sidewall, worm under), drainage will be better facilitated if done at or near the operating temperature. Filling from this location is not recommended, as the shield will impede the oil flow rate. Bearings are splash lubricated provided the input speed is 1160 RPM or greater. Contact the factory when input speeds fall below this.

B. Double reduction models are built to accommodate one mounting position as specified during order entry. Standard mounting positions, furnished unless otherwise specified, are shown in Figure 2 which also illustrates the utility plug locations. Note that the mounting position relates to the main housing orientation. Standard units have an oil level common to both housings and do not use an intermediate oil seal. The vent plug is located in the main housing where the slower worm speed eliminates the need for a vent shield. Grease fittings (not shown in Figure 2) are used to lubricate bearings when oil splash does not serve this purpose (as with the DV or DL upper slow speed bearing).

#### 3. Venting

During operation, the heat generated by the gearbox will cause the air and lubricant inside the unit to expand. A vent plug is used to equalize the resulting pressure, the location of which is dependent on the model and mounting position. Before putting the unit into service, review Figures 1 and 2 and relocate the vent plug (if necessary) as shown for the appropriate model and mounting position. Double reduction models (Figure 2) are vented in the main housing only. To prevent loss of oil during shipment, the vent plug includes a brass pin which must be removed prior to operation. If a speed reducer is installed in an atmosphere containing exceptional amounts of moisture or dust, a shielded or hooded vent plug should be used. For intermittent duty applications, where the operating temperature does not rise more than about 20 degrees F, internal pressure build-up is minimal and venting is not necessary. Some models are available with an optional internal expansion chamber allowing units to be totally sealed. Contact us for more details.

#### 4. C-Flange Motor Mounting Procedures

#### A. Mounting Motor to C-Flange Reducer With Hollow Input Shaft

Check motor and reducer mounting registers for nicks that would interfere with assembly. Remove if necessary.

Remove protective plastic plug from reducer input shaft. The bore has been coated with an anti-seize compound.

Align the motor shaft and key with keyway in bore and slide motor up to flange.

Position the motor conduit box as desired.

Using the fasteners supplied, secure the motor to the reducer. Draw down evenly so as not to bend the motor shaft. Tighten fasteners to 200 inch pounds.

#### B. Mounting Motor to C-Flange Reducer With Coupling Adaptor

Check motor and reducer mounting registers for nicks that would interfere with assembly. Remove if necessary.

When assembling the motor and coupling, the coupling halves should be equally spaced on each shaft to insure adequate engagement. The following describes a method for doing this.

First determine the assembled shaft clearance by measuring the distance from the C-Flange face to the reducer shaft end and subtracting the motor shaft length. Mount and secure the motor shaft coupling half with the spider end extending one half the clearance distance beyond the motor shaft. Mount the reducer coupling half and coupling spider on reducer shaft in its approximate position but do not secure.

Locate the motor conduit box in the desired position and secure the motor to the reducer flange using the fasteners provided. Tighten to about 200 inch pounds.

Using the access hole in the flange, slide the coupling together and tighten the set screw.

#### 5. Unit Assembly/Disassembly Instructions

Contact the factory for an instruction manual.

## III. LUBRICATION & MAINTENANCE

#### 1. Factory Filling

WINSMITH speed reducers are oil filled at the factory to the proper level for the standard mounting

position as shown in Figures 1 or 2. The oil level should be checked and adjusted (if necessary) prior to operation, using the oil level plug provided and while the unit is oriented in its operating position.

#### 2. Ambient Temperature

If the operating ambient temperature is other than 51-95°F, then refer to lubrication chart and refill the unit with the correct grade based on actual ambient temperatures and operating speed. See item 3 for additional information regarding oil changes.

#### 3. Oil Changing

When changing oil for any reason, it should be remembered that oils of various types may no be compatible. Therefore, when changing to a different oil, it is recommended that the housing be completely drained and thoroughly flushed with a light flushing oil prior to refilling with the appropriate lubricant. The oil level should be rechecked after a short period of operation and adjusted, if necessary. When changing double reduction models, each housing should be drained and filled independently, even though there may be a common level.

#### A. Initial Oil Change

The oil in a new speed reducer should be changed at the end of 250 hours of operation. (30 days for 8 hour per day service, 15 days for 16 hour service, 10 days for 24 hour service).

#### **B. Subsequent Oil Changes**

Under normal conditions, after the initial oil change, the oil should be changed after every 2500 hours of operation, or every six months, whichever occurs first. Under severe conditions (rapid temperature changes, moist, dirty or corrosive environment) it may be necessary to change oil at intervals of one to three months. Periodic examination of oil samples taken from the unit will help establish the appropriate interval.

#### C. Synthetic Oils

Synthetic lubricants can be advantageous over mineral oils in that they generally are more stable, have a longer life, and operate over a wider temperature range. These oils are appropriate for any application but are especially useful when units are subjected to low start-up temperatures or high operating temperatures. However, continuous operation above 225°F may cause damage to seals or other components. It is recommended that the initial oil be changed or filtered after the first 1500 hours of operation to remove metal particles that accumulate during break-in. Subsequent oil



Level Plug Drain



Plug locations apply to motorized units also.

Contact the factory when input speeds are less than 1160 RPM to insure proper lubrication.

\*Double Reduction units are not universal mounting. Mountings other than standard require a special outline.

DSRD

6

ര

DSFD

OTHER ATTACHMENT HOUSING POSITIONS

DSND

E

£

 $\bigcirc$ 

DSNX

HC)

 $\bigcirc$ 

DSFX

OTHER ATTACHMENT HOUSING POSITIONS

DSRX

0

**Figure 2. Double Reduction Models** 

changes should be made after 5000 hours operation if units are operating in a clean environment. This can be extended to 10,000 hours if using new reformulated Mobil SHC lubricants (orange in color) and the lubricant remains free of contamination over this period. See comments under 3B for more severe ambient conditions.

#### 4. Long Term Storage or Infrequent Operation

If a speed reducer is to stand idle for an extended period of time, either prior to installation or during use, it is recommended that the unit be filled completely with oil to protect interior parts from rust corrosion due to internal condensation. Be sure to drain the oil to the proper level before placing the speed reducer in service. A long term storage option is available on new units. Contact us for details.

#### 5. Grease Fittings

Some units are equipped with grease fittings to lubricate bearings not adequately lubricated by the oil splash. These fittings must be lubricated every 3-6 months depending on operating conditions. Bearing greases must be compatible with the type of gear lubricant being used (ie. mineral, synthetic, food grade, etc.) For mineral oils, use a high quality lithium base NLGI #2 bearing grease. For synthetic oils, use a synthetic bearing grease such as Mobil Synthetic Universal grease, Mobilith SHC 100 or a suitable equivalent. For food grade lubricants, use Chevron FM grease, NLGI 2, or equivalent.

#### 6. Low Input Speeds (Under 1160 RPM)

When input speeds are less than 1160 RPM, grease fittings will be required to lubricate any bearings not partially covered by the normal oil level. Such units are considered non-standard and necessitate factory modification. If this low speed operating condition exists and units are without the appropriate grease fittings, please contact the factory.

#### 7. Oil Temperature

Speed reducers in normal operation can generate temperatures up to 200°F depending on the type of reducer and the severity of the application (loading, duration of service, ambient temperatures). Excessive oil temperatures may be the result of one or more of the following factors:

#### A. Overloads

Overloads may be due to the original unit selection being too small for the application, or increased loads on the speed reducer to a point where its rating is exceeded after it has been in service for a period of time. Always check the speed reducer rating when increasing driven loads or increasing the horsepower rating of the motor or other prime mover.

#### B. Overfilling or Underfilling

If a speed reducer is overfilled with oil, the energy used in churning the excessive oil can result in overheating. If this occurs, shut down the drive, remove the oil level plug and allow oil to drain until oil ceases to drain from the level hole, reinstall the oil level plug and restart the drive. If the speed reducer is underfilled, the resultant friction can cause overheating and possible damage. If this occurs, fill the speed reducer to the oil level plug hole and check the gearing for excessive wear.

#### C. Inadequate Cooling

In order to dissipate internally generated heat, the speed reducer must be installed in such a way that air can circulate freely. Tightly confined areas (inside cabinets, etc.) should be avoided. If this is not possible, forced air cooling by means of a separate blower should be used.

#### 8. Oil Seals

Although WINSMITH uses high quality oil seals and precision ground shafts to provide a superior seal contact surface, it is possible that circumstances beyond WINSMITH's control can cause oil seal leakage (damage during shipment or installation, etc.). When replacing a shaft oil seal, using the following suggestions will help to insure leak-free operation and long seal life.

- A. When installing a new seal, cover the keyway and any other surface discontinuity with smooth tape to protect the seal lip from being damaged.
- **B.** A sealant should be used between the O.D. of the seal and the I.D. of the bore into which the seal is installed. The seal bore should also be free of any burrs, nicks, or scratches.
- **C.** Be sure that the seal is not cocked in the seal bore. The outer face of the seal should be flush with the surface into which it is mounted.

## Lubricants Worm Gear Reducers

For special applications that involve severe ambient temperature extremes or a seasonal oil requirement, WINSMITH, based on extensive testing and field experience, recommends the use of Mobil SHC synthetic lubricants.

Ambient Temperature	-30 to 15°F	16 to 50°F	51 to 95°F	51 to 95°F	96 to 131°F	96 to 131°F
Final Stage Worm Speed*	up to 2000 FPM	up to 2000 FPM	up to 450 FPM	above 450 FPM	up to 450 FPM	above 450 FPM
ISO Viscosity Grade	220	460	680	460	680	460*
AGMA Lubricant No.	5S**	#7 Compounded***	#8 Compounded***	#7 Compounded***	8 S**	7S**

Mobil	SHC 630	600W Super Cylinder	Extra Hecla Super	600W Super Cylinder	SHC 636	SHC 634
American Lubricants	SHC-90W	AGMA #7 Gear Oil	AGMA #8 Gear Oil	AGMA #7 Gear Oil	N/A	N/A
Castrol	Tribol 800/220	Tribol 1105-7C	Tribol 1105-8C	Tribol 1105-7C	Tribol 800/680	Tribol 800/460
Chevron	Tegra 220	Cylinder Oil W460	Cylinder Oil W680	Cylinder Oil W460	Tregra 680	Tegra 460
Conoco	Syncon R & 0 220	Inca Oil 460	Inca Oil 680	Inca Oil 460	N/A	Syncon R & O 460
Exxon (Esso)	Teresstic SHP 220	Spartan EP 460	Spartan EP 680	Spartan EP 460	Teresstic SHP 680	Teresstic SHP 460
Fiske Brothers	SPO-MG	SPO-277	SPO-288	SPO-277	N/A	N/A
Shell	Omala RL 220	Valvata J 460	Valvata J 680	Valvata J 460	Omala RL 680	Omala RL 460
Техасо	Pinnacle 220	Vanguard 460	Vanguard 680	Vanguard 460	Pinnacle 680	Pinnacle 460

\*\*synthetic oil

\*\*\*3% to 10% fatty or synthetic oils or mild EP additives

Lubricant selections are provided by the lubricant manufacturer based on AGMA recommended viscosity grades. Viscosity grades are based on Lubrication Standard ANSI/AGMA 9005-D94.

\*The sliding velocity in feet per minute (FPM) for standard ratios is determined by multiplying the speed of the worm in RPM by the factor from the following table. For selecting the proper lubricant, use the speed of the worm in the final stage (input RPM divided by the first stage ratio).

Nominal Ratio												
SIZE	5	7.5	10	15	20	25	30	40	50	60	80	100
910	0.153	_	0.137	0.133	0.122	0.116	0.132	0.121	0.115		_	_
913	0.231	0.189	0.183	0.179	0.171	0.165	0.178	0.169	0.164	0.161	_	_
917	0.303	0.229	0.201	0.193	0.180	0.172	0.189	0.176	0.170	0.166	0.161	0.133
920	0.347	0.263	0.225	0.216	0.202	0.191	0.215	0.200	0.188	0.182	0.164	0.161
924	0.412	0.312	0.261	0.256	0.236	0.223	0.249	0.231	0.216	0.210	0.201	0.196
926	0.455	0.345	0.283	0.276	0.254	0.238	0.269	0.249	0.234	0.225	0.215	0.210
930	0.520	0.395	0.327	0.317	0.291	0.273	0.307	0.285	0.269	0.258	0.246	0.241
935	0.607	0.461	0.427	0.412	0.373	0.349	0.403	0.367	0.345	0.330	0.311	0.299
943	0.633	0.588	0.568	0.553	0.507	0.558	0.544	0.501	0.475	0.457	0.435	0.422





PEERLESS-WINSMITH, INC.

SPRINGVILLE OPERATIONS • 172 EATON STREET, P.O. BOX 530, SPRINGVILLE, NY 14141-0530 PHONE: 716/592-9310 • FAX: 716/592-9546 http://www.winsmith.com e-mail=winsmith@winsmith.com



